



HoloLens as a Tool for Computer Vision Research

ECCV 2018


Johannes Schönberger



Agenda

1. Setup
2. Usage
3. Applications

Research Mode Sensors



Research Mode Requirements

- **Windows 10 (Version 1803 or newer)**
 - Desktop
 - HoloLens
- **Visual Studio 2017 (Version 15.3 or newer)**
 - Download free copy of community edition
(also works with professional and enterprise editions)
 - Install C++, UWP, Windows SDK components
(in the Visual Studio installer)

Device Portal for HoloLens


- Manage HoloLens remotely over WIFI / USB ([More Info](#))

The screenshot displays the 'Apps manager - Windows Device Portal' interface. On the left is a navigation pane with options: Apps manager, Xbox Live, File explorer, Running processes, Performance, Debug, ETW logging, Performance tracing, Device manager, Networking, Crash data, Features, Mixed Reality, Streaming Install Debugger, Location, and Scratch. The main area is titled 'Installed apps' and includes an 'Add' button. Below this is a dropdown menu and buttons for 'Remove' and 'Start'. A red message states 'System apps can't be removed' with details: Version: 10.0.17047.1000, Publisher: CN=Microsoft Windows, O=Microsoft Corporation, L=Redmond, S=Washington, C=US, and PackageFullName: 1527c705-839a-4832-9118-54d48d6a0c89 10.0.17047.1000 neutral neutral cw5n1h2trvewv. The 'Running apps' section has 'Pause updates' and 'Refresh apps' buttons. It contains a table with columns: Process Name, Package Name, CPU, Private Working Set, Working Set, Commit Size, and Package Full Name.

Process Name	Package Name	CPU	Private Working Set	Working Set	Commit Size	Package Full Name
RuntimeBroker.exe	Microsoft Edge	0.00%	8.1 MB	40.1 MB	24.2 MB	Microsoft.Micro
HxTsr.exe	Mail and Calendar	0.00%	6.6 MB	27.3 MB	13.9 MB	microsoft.wind
RuntimeBroker.exe	Movies & TV	0.00%	1008.0 KB	8.0 MB	5.7 MB	Microsoft.Zune
RuntimeBroker.exe	Microsoft Photos	0.00%	840.0 KB	7.1 MB	5.8 MB	Microsoft.Wind
RuntimeBroker.exe	Windows Default Lock Screen	0.00%	4.4 MB	30.9 MB	12.9 MB	Microsoft.Lock
TabExperienceHost.exe	Windows Shell Experience	0.11%	12.6 MB	55.0 MB	39.9 MB	Microsoft.Wind
SystemSettings.exe	Settings	0.00%	30.1 MB	93.3 MB	41.3 MB	windows.imme
MicrosoftEdgeCP.exe	Microsoft Edge	0.00%	191.1 MB	255.9 MB	228.4 MB	Microsoft.Micro
ShellExperienceHost.exe	Windows Shell Experience	0.00%	42.1 MB	125.3 MB	66.2 MB	Microsoft.Wind
SearchUI.exe	Cortana	0.00%	105.1 MB	198.9 MB	131.3 MB	Microsoft.Wind
RuntimeBroker.exe	Windows Shell Experience	0.00%	4.6 MB	32.7 MB	14.1 MB	Microsoft.Wind


Enabling Research Mode

- Device portal makes it easy to enable Research Mode
- Just don't forget to reboot your device afterwards!



Device Portal for HoloLens

- Live 3D viewer of head tracking, mesh, etc.




Device Portal for HoloLens

- Provides REST API for management ([More Info](#))
 - Access files, download meshes, etc.
 - For example, check battery status:
<http://127.0.0.1:10080/api/power/battery>

Research Mode Sensor Streams

- Grayscale HeT cameras (4 streams)
- Color photo-video camera (1 streams)
- ToF cameras (4 streams)
 - Short-throw / long-throw
 - Depth / reflectivity



Research Mode API


- Low-level access
 - Timestamps
 - Sensor images
 - Sensor poses
 - 6 DOF extrinsic calibration
 - Sensor calibration
 - Undistortion map from pixels to rays

Research Mode API

- No low-level access needed (but possible)
- We made it easy for you: ***HoloLensForCV***
<https://github.com/Microsoft/HoloLensForCV>
 - Higher-level abstraction of Research Mode API
(see Shared/HoloLensForCV/ folder)
 - Sample Desktop/HoloLens applications and tools
(see Samples/ and Tools/ folders)

HoloLensForCV Features

- Frame synchronization




The screenshot shows a web browser window with the address bar displaying "GitHub, Inc. [US] https://github.com/Microsoft/HoloLens". The browser tab is labeled "HoloLensForCV/AppMain". The main content area displays C# code for frame synchronization, with line numbers 252 through 268 visible on the left. The code defines a timestamp tolerance and uses a multi-frame buffer to find a common time for two sensors (VisibleLightLeftFront and VisibleLightRightFront) and then retrieves the corresponding frames for each.

```
252     const float c_timestampTolerance = 0.001f;
253
254     auto commonTime = _multiFrameBuffer->GetTimestampForSensorPair(
255         HoloLensForCV::SensorType::VisibleLightLeftFront,
256         HoloLensForCV::SensorType::VisibleLightRightFront,
257         c_timestampTolerance);
258
259     HoloLensForCV::SensorFrame^ leftFrame = _multiFrameBuffer->GetFrameForTime(
260         HoloLensForCV::SensorType::VisibleLightLeftFront,
261         commonTime,
262         c_timestampTolerance);
263
264     HoloLensForCV::SensorFrame^ rightFrame = _multiFrameBuffer->GetFrameForTime(
265         HoloLensForCV::SensorType::VisibleLightRightFront,
266         commonTime,
267         c_timestampTolerance);
268
```

HoloLensForCV Features


- Easily interface with OpenCV



```
44  
45     cv::Mat wrappedImage;  
46  
47     rmcv::WrapHoloLensVisibleLightCameraFrameWithCvMat(  
48         frame,  
49         wrappedImage);  
50
```

HoloLensForCV Features

- Undistortion using camera intrinsics




```
107
108     Windows::Foundation::Point uv;
109
110     uv.X = static_cast<float>(markerCorners[j].x);
111     uv.Y = static_cast<float>(markerCorners[j].y);
112
113     Windows::Foundation::Point xy;
114
115     if (!frame->SensorStreamingCameraIntrinsics->MapImagePointToCameraUnitPlane(uv, &xy))
116     {
117         continue;
118     }
119
```

HoloLensForCV Demo


- How to get started
 - Open HoloLensForCV solution in Visual Studio
 - Select «Release/x86» configuration
 - Connect and pair HoloLens via WIFI/USB ([More Info](#))
 - Deploy device applications to HoloLens
(Select the project next to «Release/x86» lists, select «Device» as the target, start new instance of project or deploy with right click on project in the solution explorer)
- Tips for debugging on device
 - Select «Release» mode («Debug» mode most likely be too slow on the HoloLens)
 - Use logging/tracing with `dbg::trace("your message %d", your_int)`
 - Wrap code with breakpoints in `#pragma optimize("", off/on)`

Research Mode Scenarios




Research Mode Samples

- Sensor stream viewer




Research Mode Samples

- Marker tracking, triangulation, and rendering



Research Mode Samples

- Wide field of view person tracking (MSR Cambridge)



Research Mode Samples

- Dense multi-view stereo from tracking cameras (MSR Redmond)



Research Mode Samples

- Streamer/Receiver applications
 - Stream sensor data from HoloLens to Desktop over WIFI/USB
(Make sure to be on the same local network, find the IP address of the HoloLens in the device portal or on the HoloLens under Settings/Network/WIFI/Advanced Settings)
 - Process/visualize sensor streams on computer
(Specify the IP address of the HoloLens as described above, specify the right ports for the stream as defined in the streamer application code)

Research Mode Samples


- Recorder application
 - Store sensor streams on HoloLens for later offline processing
 - Download the data using the device portal file browser

or

Download/Process the data using the recorder_console.py script
(see following slides for details)

Using HeT Cameras for 3D Reconstruction

- Record sensor streams using HoloLensForCV tool
- Process data offline on desktop



- COLMAP: End-to-end image-based 3D reconstruction pipeline
Open Source (pre-built binaries available) - <https://github.com/colmap/colmap>

Instructions

Record dataset on HoloLens

1. Open HoloLensForCV: Recorder application
2. Tap/click to start recording sensor streams
3. Walk around and capture scene
4. Tap/click to end recording

Instructions

Download and reconstruct on desktop

1. Start the console script

```
$ python .\HoloLensForCV\Samples\py\recorder_console.py \
    --dev_portal_user "user" \
    --dev_portal_password "password" \
    --workspace_path C:\Path\To\Workspace
```

```
Connecting to HoloLens Device Portal...
=> Connected to HoloLens at address: http://127.0.0.1:10080
Searching for CV: Recorder application...
=> Found CV: Recorder application with name: 7A37D94C-C432-4875-8C57-...
Searching for recordings...
=> Found a total of 6 recordings
```

Available commands:

help:	Print this help message
exit:	Exit the console loop
list:	List all recordings
list device:	List all recordings on the HoloLens
list workspace:	List all recordings in the workspace
download X:	Download recording X from the HoloLens
delete X:	Delete recording X from the HoloLens
delete all:	Delete all recordings from the HoloLens
extract X:	Extract recording X in the workspace
reconstruct X:	Perform sparse and dense reconstruction of recording X in workspace
reconstruct sparse X:	Perform sparse reconstruction of recording X in workspace

Instructions

Download and reconstruct on desktop

2. List recordings

```
>>> list
```

```
Device recordings:
[ 0] HoloLensRecording_2018_06_10_12_17_58
[ 1] HoloLensRecording_2018_06_10_12_36_17
[ 2] HoloLensRecording_2018_06_10_12_39_00
[ 3] HoloLensRecording_2018_06_10_12_41_25
[ 4] HoloLensRecording_2018_06_10_12_44_11
[ 5] HoloLensRecording_2018_06_10_12_46_38
Workspace recordings:
=> No Recordings found in workspace
```

3. Download recording (can also extract/delete recording)

```
>>> download 0
```

```
=> Downloading ...
...
```

```
>>> list workspace
```

```
Workspace recordings:
[ 0] HoloLensRecording_2018_06_10_12_17_58
```



HoloLensRecording_2018_06_10_12_17_58

- long_throw_depth
- long_throw_depth.tar
- long_throw_depth_camera_space_projection.bin
- long_throw_reflectivity
- long_throw_reflectivity.tar
- long_throw_reflectivity_camera_space_projection.bin
- recording_version_information
- short_throw_depth
- short_throw_depth.tar
- short_throw_depth_camera_space_projection.bin
- short_throw_reflectivity
- short_throw_reflectivity.tar
- short_throw_reflectivity_camera_space_projection.bin
- vlc_lf
- vlc_lf.tar
- vlc_lf_camera_space_projection.bin
- vlc_ll
- vlc_ll.tar
- vlc_ll_camera_space_projection.bin
- vlc_rf
- vlc_rf.tar
- vlc_rf_camera_space_projection.bin
- vlc_rr
- vlc_rr.tar
- vlc_rr_camera_space_projection.bin

Visible Light Camera
Right Right

Sensor poses
Raw images
Distortion map

Instructions

Download and reconstruct on desktop

3. (Optional) Reconstruct recording

```
>>> reconstruct 0
```

```
=> Sparse Reconstruction ...
```

```
...
```


```
=> Dense Reconstruction ...
```

```
...
```

- Reconstruction code as an example for:
 - Sensor frame synchronization / resampling
 - Absolute camera pose extraction
 - Automatic camera calibration and undistortion


COLMAP Reconstruction – MSR Building 99

- Initial HoloLens camera poses




COLMAP Reconstruction – MSR Building 99

- Sparse reconstruction



Long-term loop closure constraints



COLMAP Reconstruction – MSR Building 99


- Dense reconstruction
(from HeT cameras only)



COLMAP Reconstruction – MSR Building 99

- Dense reconstruction (from HeT cameras only)

Top View



Side View

